


# REPLACEMENT PARTS - MODEL RM4625

## 2-CYCLE CULTIVATOR

PPN 21BK125G983



Item	Part No.	Description
1	753-06833	Rear Housing (includes 2, 3 and 20)
2	791-18186	Screw
3	791-181345	Screw
4	753-06792	Muffler Assembly
5	753-06847	Spark Plug
6	791-182723	Screw
7	753-06184	O-Ring
8	753-06189	Insulator Assembly (includes 7 and 9)
9	753-06185	O-Ring
10	753-06423	Carburetor
11	753-06839	Lead Wire
12	791-182405	Switch Assembly
13	753-06253	Gasket
14	753-06834	Air Cleaner Base
15	753-05253	Screw
16	753-06835	Plate
17	753-06836	Filter
18	753-06837	Air Cleaner Cover
19	753-06838	Screw

Item	Part No.	Description
20	753-06174	O-Ring
21	753-06275	O-Ring
22	753-06841	Shortblock (includes 5, 6, 21, 23 - 25)
23	753-06840	Module
24	753-06175	Flywheel
25	753-06247	Washer
26	753-08404	Starter Housing Assembly
27	791-181862	Screw
28	753-06218	Spacer
29	753-05860	Clutch Assembly
30	753-06843	Clutch Cover
31	753-06844	Bolt
32	9689A	Screw
33	791-181345	Screw
34	753-06845	Rubber Spacer
35	712-0161	Nut
36	753-06846	Fuel Tank (includes 37 and 38)
37	791-182612	Fuel Cap
38	9206A	Fuel Tank Screw

# REPLACEMENT PARTS - MODEL RM4625 2-CYCLE CULTIVATOR PPN 21BK125G983

Item	Part No.	Description
1	753-06808	Throttle
2	753-06319	Handle
3	753-05940	Spring
4	753-06831	Throttle Cable
5	753-06832	Cap
6	10591	Eyelet Bolt
7	753-05527	Nut
8	791-182899	Bolt
9	753-04052	Washer
10	791-182677	Knob
11	753-06809	Handle
12	753-04060	Screw
13	753-06813	Upper Bracket
14	753-06814	Lower Bracket
15	753-04061	Nut
16	710-1026	Bolt
17	753-04052	Washer
18	753-04061	Nut
19	753-06810	Shield
20	753-06812	Tube (includes 21)
21	753-04499	Flex Shaft
22	753-06817	Square Tube
23	753-06969	Clevis Pin
24	753-04057	Cotter Pin
25	753-06816	Axle
26	753-06815	Spacer
27	791-182910	Washer
28	753-04437	Wheel (includes 29)
29	753-04062	Cap
30	753-06811	Clip
31	753-05983	Tine (Left Inner, Right Outer)
32	753-05984	Tine (Left Outer, Right Inner)
33	791-182195	Screw
34	791-180288	Screw
35	753-06063	Gearbox (includes 33)

